

# **USER MANUAL**

## **ANALOG FOX SONIC BREAKER**

### **Overview**

Analog Fox Sonic Breaker is an effects pedal that combines the circuits of Marshall Blues Breaker Overdrive and Maxon Sonic Distortion.

All parts' values are exactly the same as in the old original units.

### **Panel Descriptions**

#### ***Top line of knobs***

Dist, Tone and Level are controls for the Distortion side of the circuit.

#### ***Bottom line of knobs***

Drive, Tone and Level are controls for the Overdrive side of the circuit.

#### ***"First" switch***

Sets the order of the effects.

Down - Overdrive goes before Distortion;

Up - Distortion goes before Overdrive.

#### ***Footswitches***

Dist - True bypass switch that turns distortion on/off;

Drive - True bypass switch that turns overdrive on/off.

### **Important Note**

Notice the silver screw near the output jack of the pedal – it delivers ground to the top side of the enclosure. It should be screwed tightly for the sheilding to work properly.

### **Secifications**

#### ***Power Supply***

DC 9-18V Center negative (Standard Boss style adapter) or 9v battery

#### ***Current Draw***

12mA when powered from 9v battery

***Dimensions***

11.5 x 9.5 x 5.8 cm / 4.5 x 3.7 x 2.3 inch

***Weight***

519 g / 18,3 oz (including battery)

**Warranty**

The pedal is covered by 5 year international warranty which means:

1. If you get a faulty pedal - we replace it or refund. And we refund all shipping costs.
2. If a pedal breaks within 1 year - we repair it and refund the shipping costs.
3. If a pedal breaks within 5 years - we repara for free, but charge you for the shipping.

**Contacts**

If you have any questions - pls send us a message: [motion2freedom@gmail.com](mailto:motion2freedom@gmail.com)